

Axis Sight Leveler

Proper-use Instructions

The October Mountain Products Sight Leveler has been optimized for use with the Versa-Cradle series of bow vises. For use without a Versa-Cradle Bow Vise, a clamp and 45° shim (for 3rd axis adjustment) is recommended.

For Use with an OMP Versa-Cradle:


1. Clamp the sight leveler frame (4) in place using the Versa-Cradle limb c-clamp and tighten.
2. Install the sight to the leveler at the sight mounting hole (1) locations.
3. Level the vise, using the horizontal (2) and vertical (3) levels.
4. Per the manufacturer's sight instructions, level the second axis.
5. Once the sight bubble is adjusted for second axis, the vise can now be loosened to lean the sight at approximately 45° for third axis leveling.
6. Once complete, your sight is ready to be installed to your bow.

For Use without an OMP Versa-Cradle:

1. Level the Sight Leveler to a workbench using the three leveling screws (5) and levels (2 & 3). Adjust the leveling screws until level.
2. Hold in place using a c-clamp.
3. Install the sight to the leveler at the sight mounting hole (1) locations.
4. Per the manufacturer's sight instructions, level the second axis.
5. Once the sight bubble is adjusted for second axis, the leveler can now be angled so the sight is at approximately 45° for third axis leveling. It is recommended that a 45° block or shim (not provided) is used to aid in this step.
6. Once complete, your sight is ready to be installed to your bow.



SECOND AXIS



THIRD AXIS



Forward and back like a door hinge

For video instructions, visit OctoberMountainProducts.com/media

Product Support: 717-492-8020 | Info@OctoberMountainProducts.com

OctoberMountainProducts.com



Follow us

Components



Axis Sight Leveler

- 1 Sight Mounting Holes
- 2 Horizontal Level
- 3 Vertical Level
- 4 Frame
- 5 Leveling Screws
- 6 Magnet



*Note: Magnet is for use with a metal surface.
For best results, still use a c-clamp.*



**Best performance when
paired with Versa-Cradles**